



CallPilot Fax User Guide

Avaya Business Communications Manager Release 6.0

Document Status: **Standard**

Document Number: **NN40080-100**

Document Version: **03.02**

Date: **October 2010**

© 2010 Avaya Inc.
All Rights Reserved.

Notices

While reasonable efforts have been made to ensure that the information in this document is complete and accurate at the time of printing, Avaya assumes no liability for any errors. Avaya reserves the right to make changes and corrections to the information in this document without the obligation to notify any person or organization of such changes.

Documentation disclaimer

Avaya shall not be responsible for any modifications, additions, or deletions to the original published version of this documentation unless such modifications, additions, or deletions were performed by Avaya. End User agree to indemnify and hold harmless Avaya, Avaya's agents, servants and employees against all claims, lawsuits, demands and judgments arising out of, or in connection with, subsequent modifications, additions or deletions to this documentation, to the extent made by End User.

Link disclaimer

Avaya is not responsible for the contents or reliability of any linked Web sites referenced within this site or documentation(s) provided by Avaya. Avaya is not responsible for the accuracy of any information, statement or content provided on these sites and does not necessarily endorse the products, services, or information described or offered within them. Avaya does not guarantee that these links will work all the time and has no control over the availability of the linked pages.

Warranty

Avaya provides a limited warranty on this product. Refer to your sales agreement to establish the terms of the limited warranty. In addition, Avaya's standard warranty language, as well as information regarding support for this product, while under warranty, is available to Avaya customers and other parties through the Avaya Support Web site: <http://www.avaya.com/support>

Please note that if you acquired the product from an authorized reseller, the warranty is provided to you by said reseller and not by Avaya.

Licenses

THE SOFTWARE LICENSE TERMS AVAILABLE ON THE AVAYA WEBSITE, [HTTP://SUPPORT.AVAYA.COM/LICENSEINFO/](http://support.avaya.com/licenseinfo/) ARE APPLICABLE TO ANYONE WHO DOWNLOADS, USES AND/OR INSTALLS AVAYA SOFTWARE, PURCHASED FROM AVAYA INC., ANY AVAYA AFFILIATE, OR AN AUTHORIZED AVAYA RESELLER (AS APPLICABLE) UNDER A COMMERCIAL AGREEMENT WITH AVAYA OR AN AUTHORIZED AVAYA RESELLER. UNLESS OTHERWISE AGREED TO BY AVAYA IN WRITING, AVAYA DOES NOT EXTEND THIS LICENSE IF THE SOFTWARE WAS OBTAINED FROM ANYONE OTHER THAN AVAYA, AN AVAYA AFFILIATE OR AN AVAYA AUTHORIZED RESELLER, AND AVAYA RESERVES THE RIGHT TO TAKE LEGAL ACTION AGAINST YOU AND ANYONE ELSE USING OR SELLING THE SOFTWARE WITHOUT A LICENSE. BY INSTALLING, DOWNLOADING OR USING THE SOFTWARE, OR AUTHORIZING OTHERS TO DO SO, YOU, ON BEHALF OF YOURSELF AND THE ENTITY FOR WHOM YOU ARE INSTALLING, DOWNLOADING OR USING THE SOFTWARE (HEREINAFTER REFERRED TO INTERCHANGEABLY AS "YOU" AND "END USER"), AGREE TO THESE TERMS AND CONDITIONS AND CREATE A BINDING CONTRACT BETWEEN YOU AND AVAYA INC. OR THE APPLICABLE AVAYA AFFILIATE ("AVAYA").

Copyright

Except where expressly stated otherwise, no use should be made of the Documentation(s) and Product(s) provided by Avaya. All content in this documentation(s) and the product(s) provided by Avaya including the selection, arrangement and design of the content is owned either by Avaya or its licensors and is protected by copyright and other intellectual property laws including the sui generis rights relating to the protection of databases. You may not modify, copy, reproduce, republish, upload, post, transmit or distribute in any way any content, in whole or in part, including any code and software. Unauthorized reproduction, transmission, dissemination, storage, and/or use without the express written consent of Avaya can be a criminal, as well as a civil offense under the applicable law.

Third Party Components

Certain software programs or portions thereof included in the Product may contain software distributed under third party agreements ("Third Party Components"), which may contain terms that expand or limit rights to use certain portions of the Product ("Third Party Terms"). Information regarding distributed Linux OS source code (for those Products that have distributed the Linux OS source code), and identifying the copyright holders of the Third Party Components and the Third Party Terms that apply to them is available on the Avaya Support Web site: <http://support.avaya.com/Copyright>.

Trademarks

The trademarks, logos and service marks ("Marks") displayed in this site, the documentation(s) and product(s) provided by Avaya are the registered or unregistered Marks of Avaya, its affiliates, or other third parties. Users are not permitted to use such Marks without prior written consent from Avaya or such third party which may own the Mark. Nothing contained in this site, the documentation(s) and product(s) should be construed as granting, by implication, estoppel, or otherwise, any license or right in and to the Marks without the express written permission of Avaya or the applicable third party. Avaya is a registered trademark of Avaya Inc. All non-Avaya trademarks are the property of their respective owners.

Downloading documents

For the most current versions of documentation, see the Avaya Support. Web site: <http://www.avaya.com/support>

Contact Avaya Support

Avaya provides a telephone number for you to use to report problems or to ask questions about your product. The support telephone number is 1-800-242-2121 in the United States. For additional support telephone numbers, see the Avaya Web site: <http://www.avaya.com/support>

Task List

CallPilot Fax User Guide	7
To check which mailbox interface you use	11
To record a mailbox greeting	13
To transfer a fax call to your mailbox	14
To open your mailbox — Norstar Voice Mail	15
To open your mailbox — CallPilot	15
To assign a preset fax machine	17
To print all fax messages	18
To print an individual fax message	19
To print fax messages from a fax telephone	20
To send a fax message to a personal mailbox	21
To forward a fax message to a mailbox — Norstar Voice Mail	23
To forward a fax message to a mailbox — CallPilot	24
To forward a fax message to an external number — Norstar Voice Mail	24
To forward a fax message to an external number — CallPilot	26
To send a Fax Group message — Norstar Voice Mail	28
To send a Fax Group Message — CallPilot	28

Contents

Chapter 1	
CallPilot Fax User Guide	7
About this guide	7
Audience	7
Symbols and text conventions	8
Telephone buttons	9
Related Publications	10
Learning about Fax	10
About the Express Messaging Line	10
Checking which mailbox interface you use	11
Telling callers about fax in your mailbox greeting	12
Receiving a fax message	13
Transferring a fax call to your mailbox	14
Opening your mailbox	15
Printing fax messages	15
About destinations for printing fax messages	16
Assigning a preset fax machine	16
To print all your fax messages	17
Fax cover page	21
Sending fax messages	21
Forwarding fax messages	22
About Fax Group messages	26
Adding special characters to a fax telephone number	30

Chapter 1

CallPilot Fax User Guide

About this guide

The *CallPilot Fax User Guide* explains how to use CallPilot Fax with your personal mailbox. It explains how to receive, print, and send fax messages.

To use this guide, you must determine which phone interface you use, and follow the procedures for that interface. For information about determining which interface you use, see [“Checking which mailbox interface you use” on page 11](#).



Note: If you need information about other CallPilot features, see the *CallPilot Reference Guide* or ask your system administrator.

Audience

This guide is for CallPilot Fax users.

Symbols and text conventions

These symbols are used to Highlight critical information for the <Product Name short> system:



Caution: Alerts you to conditions where you can damage the equipment.



Danger: Alerts you to conditions where you can get an electrical shock.



Warning: Alerts you to conditions where you can cause the system to fail or work improperly.



Note: A Note alerts you to important information.



Tip: Alerts you to additional information that can help you perform a task.



Security note: Indicates a point of system security where a default should be changed, or where the administrator needs to make a decision about the level of security required for the system.



Warning: Alerts you to ground yourself with an antistatic grounding strap before performing the maintenance procedure.



Warning: Alerts you to remove the <Product Name short> main unit and expansion unit power cords from the ac outlet before performing any maintenance procedure.



Telephone buttons

All one line and two line display telephones provide CallPilot voice prompts. On telephones with display buttons, the voice prompts are delayed for five seconds. If you do not see an option on your telephone display, wait for the voice prompt to announce the additional options.

To use Fax features, press the display buttons or the dialpad buttons on your telephone.

When you see a display button like this: **PLAY**, or a dialpad button like this: **2**, press either button to activate the CallPilot feature. This guide shows you both methods.

This table shows the Business Series Terminal buttons. Use the buttons that pertain to the type of telephone you use.

Button name	Avaya 7000 Series Digital Deskphones	M7100, M7208, M7310, M7324	M7100N, M7208N, M7310N, M7324N
Feature			
Handsfree	Bottom right-hand button		
Hold			
Volume Control			
Release			

You can enter ,  or  and the code to use a feature.

For example, press  **9** **8** **1** to access your mailbox.

The Avaya 7100 Digital Deskphone works differently from other telephones on your system because it does not have line buttons. Where other telephones require that you select a line button to answer a call, on the Avaya 7100 Digital Deskphone terminal you pick up the handset. Where other telephones require you to select a line button to take a call off hold, you press  on the Avaya 7100 Digital Deskphone terminal.

On Avaya 7100 Digital Deskphone terminals, you can answer a second call by pressing . Your active call is put on hold and you connect to the waiting call. You can have no more than two active calls at one time.

These conventions and symbols are used to represent the Business Series Terminal display and dialpad.

Convention	Example	Used for
Word in a special font (shown in the top line of the display)	Pswd:	Command line prompts on display telephones.
Underlined word in capital letters (shown in the bottom line of a two line display telephone)	<u>PLAY</u>	Display option. Available on two line display telephones. Press the button directly below the option on the display to proceed.

Convention	Example	Used for
Dialpad buttons	#	Buttons you press on the dialpad to select a particular option.

Related Publications

This section provides a list of additional documents referred to in this guide.

CallPilot Reference Guide (NN40090-100)

Learning about Fax

With CallPilot Fax you can access Fax features from your personal mailbox.

A fax document in a mailbox is called a fax message. Fax messages can have a voice introduction. This means that a caller can leave a fax message with or without an introductory voice message in your personal mailbox.

You can:

- retrieve and print the fax message on a fax machine
- forward the fax message to another mailbox

About the Express Messaging Line

You can have an Express Messaging Line assigned to your mailbox. An Express Messaging Line allows you to send only a fax message when the fax only option is selected or to send voice and fax messages when the fax only option is not selected. A fax message sent to the Express Messaging Line bypasses the Automated Attendant and is sent immediately to your mailbox. You access the fax message the same way you access other fax messages. For more information about accessing fax messages, see [“Receiving a fax message” on page 13](#).

Ask your System Administrator for the telephone number of your Express Messaging Line. Then you can inform people of your direct fax line number.

Checking which mailbox interface you use


The CallPilot supports two interfaces: Norstar Voice Mail and CallPilot. The System Administrator determines which interface is assigned to your mailbox.

Use this procedure to check which mailbox interface you use, then follow the procedures in the guide that apply to the interface you use.

Some procedures apply to both interfaces.


To check which mailbox interface you use

- 1 Press  9 8 1.
Follow the voice prompts or the display button options to open your mailbox.
- 2 Check the display to see which interface you use:



0 new 0 saved
PLAY REC ADMIN

This is the Norstar Voice Mail interface.



No messages
COMP MBOX EXIT

This is the CallPilot interface.

- 3 Press  to end the session.

Telling callers about fax in your mailbox greeting

In your mailbox greeting, tell callers that they can leave fax messages in your mailbox. Tell callers that they must call from a fax machine telephone to send you a fax message. The caller must press START/SEND on the fax machine. CallPilot automatically receives and stores the fax message in your mailbox. This is an example of a Personal mailbox greeting:

“Hello. You have reached Brian Purdy with Ideal Office Machines. I am in the office today, but I am currently away from the phone. Please leave your name, telephone number and a brief message after the tone. If you want to send me a fax and you are calling from a fax machine telephone, press the START/SEND button on the fax machine now, or when this message ends.”

For more information about mailbox greetings, see the *CallPilot Reference Guide* or ask your System Administrator.



Note: Recorded greetings count towards the storage capacity of a mailbox. Avoid recording long greetings if possible. If recorded greetings are long, there will be less storage time in the mailbox for messages.

To record a mailbox greeting

- 1 Press  9 8 1 .
Follow the voice prompts or the display button options to open your mailbox.

- 2 If you use the CallPilot interface:

- Press 8 2 to open the Greetings Options menu
- Go to step 3

If you use the Norstar Voice Mail interface:

- Press ADMIN or 8
- Press GREET or 2
- Go to step 3

Greeting options
REC CHOOSE CFWD

- 3 Press REC or 1 .

Greeting:
PRIME ALT PERS

- 4 Press PRIME or 1 to record the Primary greeting
or
press ALT or 2 to record the Alternate greeting.

Record now?
YES NO QUIT

- 5 Press YES or 1 and record your greeting at the tone.

Record greeting:
RETRY OK

- 6 Press OK or # to end the recording.

Accept greeting?
RETRY PLAY OK

- 7 Press OK or # to accept the recording
or
press PLAY or 1 to listen to the greeting
or
press RETRY or 2 to re-record the greeting.

- 8 Press  to end the session.

Receiving a fax message

Fax messages can contain a voice message that a caller records to introduce the fax message, or they can contain just the fax message.

A caller can send a fax message to your personal mailbox by using the autosend feature on their fax machine. If the call is answered by the Automated Attendant, the call transfers to the designated Fax answering extension. If the call is answered by a mailbox, the fax message is placed in the mailbox. If you answer the call, you hear a fax tone. Transfer the fax call to your mailbox.


Transferring a fax call to your mailbox

If you answer a call and hear a fax tone, a caller is attempting to send a fax message to your mailbox. You can transfer the call to your mailbox.

To transfer a fax call to your mailbox

- 1 Press  9 8 6.
Do not put the call on hold.
- 2 Enter your mailbox number.
The fax message is left in your mailbox.

When you receive a message in your mailbox, your telephone display shows:



Message for you
MSG

This display indicates that you have a new voice message or a fax message in your mailbox. To check for messages, you must open your mailbox.

Opening your mailbox

To open your mailbox — Norstar Voice Mail

- 1 Press 9 8 1.

Pswd:
OTHR RETRY OK

- 2 Enter your mailbox password and press OK or or
if you are at another extension, or if you are using a Guest mailbox, press OTHR or to display the Log: prompt. When this prompt appears, enter your mailbox number and password. Your mailbox number is usually the same as your extension.

1 new 1 saved
PLAY REC ADMIN

- 3 After you open your mailbox, the telephone display shows how many new and saved messages you have.
A voice prompt announces how many new and saved voice and fax messages you have.
In this example there is one new message and one saved message.

To open your mailbox — CallPilot

- 1 Press 9 8 1.

Mbox:
RETRY OK

- 2 Press
or
if you are at another extension, enter your mailbox number and then press OK or .
Your mailbox number is usually the same as your extension.

Pswd:
RETRY OK

- 3 Enter your mailbox password and press OK or .
After you open your mailbox, the telephone display shows how many new messages you have.
A voice prompt announces how many new and saved fax messages you have.

Printing fax messages

You can print the fax messages in your mailbox on any fax machine. You can print all of your fax messages at once or individually.

An average text fax message uses 10 seconds of mailbox message time per page. A fax message that contains graphics can use as much as two minutes of mailbox message time per page. Because fax messages can take up a lot of mailbox space, after you print or forward your fax messages, delete them from your mailbox.

If you print all your fax messages at once, you cannot listen to any voice introductions that are included with the fax messages. If you do not listen to a voice introduction, the fax message remains “new” in your mailbox and you can listen to the voice introduction later.

If you print each fax message individually, you can listen to the introduction before you print the fax message.

About destinations for printing fax messages

When you print a fax message, you can print it from:

Print msg
PRESET OTHR MANU

Table 1 Fax destinations

Preset	You can set up a fax machine as the default destination. When you print and you select Preset, the fax machine prints at the default destination. Unless you specify Other, faxes print at the default destination.
Other	When you send a fax message to print and you select Other, you must enter a phone or extension number as the destination.
Manual	Select Manual if you are printing from a fax telephone. The fax messages are printed on the fax machine you use to access your mailbox.

Fax messages are preceded by a cover page if you select Preset or Other. A cover page is not added for fax messages you print from a fax telephone. For more information see [“Fax cover page” on page 21](#).

Assigning a preset fax machine

If you assign a preset fax machine, your fax messages print at the same fax machine every time.

To assign a preset fax machine

- 1 Press  9 8 1 .
Follow the voice prompts or the display button options on your telephone to open your mailbox.

- 2 If you use the CallPilot interface:

- Press 8 0 to open the Mailbox Options menu
- Press 3 to open the Fax Options menu
- Go to step 3

If you use the Norstar Voice Mail interface:

- Press ADMIN or 8
- Press 7
- Go to step 3

No Preset

- 3 This display appears if there is no preset fax machine.
If the fax machine is preset, the display shows: **Preset fax.**
If you want to assign a different machine as the preset fax machine, press CHNG.

Destination:
PHONE EXT

- 4 Press PHONE or 1 to assign the phone number of a fax machine or
press EXT or 2 to assign the extension number of a fax machine.
This example shows assigning the phone number of a fax machine.

Ph:
RETRY 

- 5 Enter the fax telephone number and press OK or #.

<>
ADD 

- 6 Press OK or # to accept the fax telephone number represented by the <>
or
press ADD to add special characters to the fax telephone number and follow the prompts.
After you add special characters press OK or #.

- 7 Press  to end the session.

To print all your fax messages

Use this procedure if you want to print all your new or saved messages.

If you want to print just one message, see [“To print an individual fax message” on page 19.](#)

To print all fax messages

- 1 Press  9 8 1.

Follow the voice prompts or the display button options on your telephone to open your mailbox.

- 2 If you use the CallPilot interface:

- Press 7 7 to open the Print Command menu
- Go to step 3

If you use the Norstar Voice Mail interface:

- Press 1
- Go to step 3

- 3 If you use the CallPilot interface:

- Press MSG or 1 to print an individual message or
- press NEW or 2 to print all unprinted fax messages or
- press ALL or 3 to print all faxes with their attachments

If you use the Norstar Voice Mail interface and you have new fax messages:

- Press NEW or 1 to print all your new fax messages or
- press SAVED or 2 to print all your saved fax messages

If you do not have any new fax messages the display in step 4 appears.

Print msg
PRESET OTHR MANU

- 4 Press PRESET or 1 if you want to print on the preset fax machine and go to step 8 or
press OTHR or 2 if you want to print on a fax machine other than the preset fax machine and go to step 5.

Destination:
PHONE EXT

- 5 Press PHONE or 1 to print fax messages at a fax telephone number or
press EXT or 2 to print fax messages at a fax extension number. This example shows entering the phone number of a fax machine.

Ph:
RETRY OK

- 6 Enter the fax telephone number and press OK or #.

```
<>
ADD      OK
```

- 7 Press **OK** or **#** to accept the fax telephone number represented by **<>**
or
press **ADD** to add special characters to the fax telephone number and follow the voice prompts.

```
Printed <> msgs
```

- 8 The display shows the number of fax messages printed.
- 9 Press **END** to end this session.

After you end the session, CallPilot prints the fax messages on the preset fax machine. For information about changing the preset fax machine, see [“Assigning a preset fax machine” on page 16](#).

To print an individual fax message

Use this procedure if you want to print an individual fax message.

- 1 Press **9 8 1**.
Follow the voice prompts or the display button options on your telephone to open your mailbox.
- 2 If you use the CallPilot interface:
 - Press **7 7** to open the Print Command menu
 - Go to step 3

If you use the Norstar Voice Mail interface:

- Press **6** until you locate the fax you want to print
- Go to step 3

```
<date> Fax:1
<<< STOP >>>
```

- 3 Wait until the prompt announces the Fax ID number, and then press **1** to print the fax message.

```
Print msg
PRESET OTHR MANU
```

- 4 Press **PRESET** or **1** to print on the preset fax machine
or
press **OTHR** or **2** if you want to specify another fax machine to print the message on, and then enter the number of the fax machine.

```
Printed msg
```

- 5 The display shows the message is printed.

```
End of message
COPY ERASE NEXT
```

- 6 Press **END** to end this session.

After you end the session, CallPilot prints the fax message on the fax machine you specified.

To print fax messages from a fax telephone

- 1 From a fax machine telephone, call into a line that is answered by the Automated Attendant.
- 2 Press , or in the UK press , to access your mailbox while the Automated Attendant Greeting plays.
- 3 Log on to your mailbox:
 - If you use the Norstar Voice Mail interface, enter your mailbox number and password and press .
 - If you use the CallPilot interface, enter your mailbox number and press , then enter your password and press .
- 4 Send the fax message to print:
 - If you use the Norstar Voice Mail interface, press to print your fax messages
 - If you use the CallPilot interface, press to print your fax messages
- 5 If you have new and saved fax messages, you can print either all new or saved fax messages:
 - press to print all new fax messages
 - press to print all saved fax messages

Step 5 is bypassed if you have only new fax messages or only saved fax messages.

- 6 Press to use the Manual option to print the new fax messages.
- 7 Press START/SEND on the fax machine.
- 8 Replace the fax machine telephone handset.
The session ends when all the faxes are printed.

CallPilot prints the fax messages on the assigned fax machine.

Fax cover page

A fax cover page prints with each fax message you print using the Preset and Other feature. The fax cover page shows:

- the date and time the fax prints
- the name and telephone number of the mailbox owner
- the destination fax number
- the Fax ID number (if you print a single fax message)
- the number of pages to follow



Note: A fax cover sheet is not added if you print a fax from a fax telephone.

Sending fax messages

To send a fax message to a personal mailbox you must call from a fax machine telephone. You can include a voice introduction to a fax message you send to a personal mailbox. The voice introduction must be at least three seconds long. The system times out after five seconds of silence.

To send a fax message to a personal mailbox

- 1 Place the document that you want to send in the fax machine.
- 2 From the fax machine telephone dial the CallPilot telephone number of the person you want to send a fax to.
- 3 Wait for the mailbox greeting or let the CallPilot operator transfer you to the mailbox to leave a fax message. If the person you are calling answers their telephone, tell them to transfer you to their mailbox so you can send a fax.
- 4 After the mailbox greeting plays, wait for a beep and record an introduction for the fax message. Do not hang up the telephone.
- 5 Press START/SEND on the fax machine.
- 6 Replace the fax machine telephone handset. The session ends when the transmission is complete.

Forwarding fax messages

You can forward a fax message that you have received to another mailbox and add a voice introduction. If you record a voice message it must be longer than three seconds. The system times out after five seconds of silence.

The message appears as a fax message in the recipient's mailbox. If you cannot forward a fax message, ask your System Administrator if your mailbox is set up to allow you to forward fax messages.

You can send the same fax message to more than one person, but not to a Group List.

For information about forwarding a fax message to an external number, see [“To forward a fax message to a mailbox — Norstar Voice Mail” on page 23](#).

When you forward a fax message, a new cover page is added to the original fax message, becoming part of the new message. If the fax message already has a CallPilot-generated fax forward cover page, it is replaced by a new fax forward cover page.

Fax forward cover page

A fax forward cover page contains the same information as a fax cover page plus:

- the recipient's name
- the Fax ID number if the fax is forwarded to an external number

To forward a fax message to a mailbox — Norstar Voice Mail

- 1 Press 9 8 1 .
Follow the voice prompts or the display button options on your telephone to open your mailbox.
- 2 Press PLAY or if you have a new fax message
or
press to review your messages until you find a saved fax message you want to forward.
- 3 The date received and the Fax ID number appear on the display.
- 4 Press COPY or .
- 5 Press MBOX or to forward the fax message to another mailbox.
- 6 Press YES or to record an introduction to the fax message
or
press NO or and go to step 10 if you do not want to record an introduction to the forwarded fax message.
- 7 Record the introduction and press OK or to end the recording
or
press RETRY or to re-record the introduction
or
press PAUSE or to pause while you record the introduction.
- 8 Press OK or to accept the recording.
- 9 Enter the mailbox number you want to forward the fax message to
or
press DIR or to search the Company Directory.
- 10 Press SEND or to forward the message without a delivery option
or
press OPTS or to assign message delivery options. For information about delivery options see the *CallPilot Reference Guide*.
- 11 To send this message to another mailbox owner,
press YES or and repeat steps 6 to 11
or
press QUIT to end the session.

<date> Fax:1
<<< STOP >>>

End of message
COPY ERASE NEXT

Copy fax
MBOX OTHR

Record Intro?
YES NO

Record message:
RETRY PAUSE OK

Accept rec?
RETRY PLAY OK

Mbox:
DIR QUIT

Wayne, Paul
OPTS CC SEND

Another copy?
YES QUIT

To forward a fax message to a mailbox — CallPilot

- 1 Press 9 8 1 .
Follow the voice prompts or the display button options on your telephone to open your mailbox.
- 2 Press to play the first message
or
press until you find the fax message you want to forward.
- 3 Press to forward the message.
- 4 Enter the mailbox number you want to forward the fax message to and press OK or .
or
press NAME or to search the Company Directory.
- 5 Press OK or to end the list of addresses.
- 6 If you want to attach a voice message, press REC or and record your message.
- 7 If you want to attach message options, press to assign message options.
- 8 Press to send the message.
- 9 Press to end the session.

End message
COPY ERASE NEXT

End message
PRINT DEL NEXT

To:
NAME SPEC CNCL

To:<xxxx>
RETRY OK

Empty
REC

Msg options
URG PRIV OTHR

To forward a fax message to an external number — Norstar Voice Mail

You can forward a received fax message to an external number. However, you cannot add an introductory voice message to the fax message.

- 1 Press 9 8 1 .
Follow the voice prompts or the display button options on your telephone to open your mailbox.
- 2 Press PLAY or to play the first message
or
press until you find the fax message you want to forward.
- 3 The date received and the Fax ID number appear on the display.

2 new 0 saved
PLAY REC ADMIN

<date> Fax:1
<<< STOP >>>

End of message
COPY ERASE NEXT

- 4 Press COPY or **5**.

Copy fax
MBOX QTHR

- 5 Press QTHR or **2**.

Name:
RETRY BKSP OK

- 6 Enter the recipient's name. The name can be a maximum of eight characters. Using the telephone dialpad, enter the name of the recipient. After each letter, press **#** to enter the next letter.

If you make an error in the name, press RETRY and re-enter the name.

Press OK to accept the name.

Destination:
PHONE EXT

- 7 Press PHONE or **1** to enter the fax telephone number.

Ph:
RETRY OK

- 8 Enter the fax telephone number and press OK or **#**.

<x>
ADD OK

- 9 Press OK or **#** to accept the fax telephone number represented here by <x>
or
press ADD to add special characters to the fax telephone number. For information about adding special characters, see [“Adding special characters to a fax telephone number”](#) on page 30.

Msg sent

- 10 CallPilot forwards the fax message.

Another copy?
YES QUIT

- 11 Press YES or **1** and repeat steps 6 to 11 to send this message to another external number
or
press QUIT if you are done.

- 12 Press **[End Call]** to end the session.

To forward a fax message to an external number — CallPilot

- 1 Press 9 8 1 .
Follow the voice prompts or the display button options on your telephone to open your mailbox.
 - 2 Press to open the Print Command menu.
- End message
 COPY ERASE NEXT
- 3 Press MSG or to forward the current message
or
press NEW or to forward all your new fax messages
or
press ALL or to forward all your new and saved fax messages.
- Print
 MSG NEW ALL
- 4 Press QTHR or to specify the fax machine you are forwarding the fax message to.
- Print msg
 PRESET QTHR MANU
- 5 Press PHONE or .
- Destination:
 PHONE EXT
- 6 Enter the phone number of the fax machine you are forwarding the fax message to.
- Ph:
 RETRY OK
- 7 Press OK or to accept the phone number
or
press ADD or to add special characters.
- <xxx>
 ADD OK
- 8 The display shows the message is printed.
- Printed msg
- 9 Press to end the session.

About Fax Group messages

Send a Fax Group message if you want to send a group a fax message that pertains to them. Fax Group Lists are created by the System Administrator.

Fax Group Lists

If you frequently fax information to the same group of people, use a Fax Group List.





A Fax Group List is a collection of fax machines at other locations. When you send a fax message to a Fax Group List, you enter only the address of the list, but each fax machine in the Fax Group List receives the fax message. Ask your System Administrator for a list of fax machines in each Fax Group List.


If you need a Fax Group List, ask your System Administrator to create one for you. When you give the System Administrator the information, include:

- the names of the recipients
- a list of the fax machine numbers
- the Fax Group List name


Before you send a Fax Group message, be sure your System Administrator has created the Fax Group List, and the list contains all the fax machines that are to receive the fax message.

To send a Fax Group message — Norstar Voice Mail

- Press 9 8 1 .
Follow the voice prompts or the display button options on your telephone to open your mailbox.
- Press **PLAY** or to play the current message
or
press until you find the fax message you want to forward.
- The date received and the Fax ID number appear on the display.

- Press **COPY** or .

- Press **MBOX** or to forward the fax message to another mailbox.

- Press **NO** or .
Do not record an introduction because Fax Group List recipients do not hear voice introductions.

- Enter the Fax Group List number.

- Press **SEND** or to send the fax message
or
press **OPTS** or to assign message delivery options
or
press **CC** to send the message to another recipient.
For information about delivery options see the *CallPilot Reference Guide*.

- Press to end the session.

To send a Fax Group Message — CallPilot

- Press 9 8 1 .
Follow the voice prompts or the display button options on your telephone to open your mailbox.
- Press **PLAY** or to play the current message
or
press until you find the fax message you want to forward.

- Press to forward the message.


To:
NAME SPEC CNCL

- 4 Enter the Group List number and press **OK** or **#**.

To:
NAME SPEC CNCL

- 5 Press **7** **3** when you have entered all the addresses you want to send the message to.

Empty
REC

- 6 If you want to attach a voice message, press **REC** or **5** and record your message.
External Group List recipients do not receive voice introductions to fax messages.

Msg options
URG PRIV OTHR

- 7 If you want to attach message options, press **7** **0** to assign message options.

Msg delivered

- 8 Press **7** **9** to send the message.
9 Press  to end the session.

Adding special characters to a fax telephone number

Follow the voice prompts or press **ADD** to add special characters to a fax telephone number.



Note: If you are adding special characters, do not press the dialpad buttons **#** to enter #, or ***** to enter *. Press the button directly below the option on a two line display telephone, or listen to the voice prompts.

Press	To
2 or DIGS	resume adding digits to the destination phone number.
3 or PAUS	enter a timed pause that appears as P on the display. Pauses are four seconds long.
4	recognize dial tone (behind PBX). The Recognize Dial Tone special character appears as D on the display.
5 or QTHR #	enter #.
6 or QTHR *	enter *.
TONE	recognize dial tone (behind PBX). The Recognize Dial Tone special character appears as D on the display.
*	cancel and retry.